

GUANTE GUANTES DE NITRILO GRIPPAZ® BY JUBA® - 580OR GRIPPAZ

"GRIPPAZ®" Nitrile disposable glove fish scale. Powder-free.



NORMATIVE



Distributed by:



CHARACTERISTICS

- Superior grip thanks to its fish scale design.
- Ambidextrous.
- Textured inside to maximize the grip.
- Good chemical resistance.
- They can be used with an inner glove.
- Maximum level of dexterity according to CE standards.
- Suitable for people allergic to latex.
- Suitable for alimentary use according to Directive 10/2011.

WORKING GLOVES SUITABLE FOR:

- Assembling.
- Spray painting.
- Maintenance of vehicles.
- General purpose.
- Cleaning services.
- Agriculture / Horticulture.
- Garages.

MORE INFO

Materials	Thickness	Length	Sizes	Packaging
Nitrile	0.15 mm	S - 24 cm M - 24 cm L - 24 cm XL - 24 cm XXL - 24 cm	7/S 8/M 9/L 10/XL 11/XXL	Cajita:50und/Caja:500und

Distributed by:



NORMATIVAS

EN ISO 374-1:2016



EN ISO 374-1:2016
TIPO X



XXXXXX

EN ISO 374-5:2016



The EN374: 2003 standard is renamed ENISO374: 2016. The purpose of this standard is to classify gloves according to their behavior when exposed to chemical substances.

They are divided into the following parts:

EN ISO 374-1:2016 - Terminology and performance requirements for chemical risks.

EN 374-2:2014 - Determination of resistance to penetration.

EN 16523-1:2015 + A1:2018 - Permeation by liquid chemicals under continuous contact conditions.

EN ISO 374-4:2019 - Determination of resistance to chemical degradation.

EN ISO 374-5:2016 - Terminology and requirements demanded for risks of microorganisms.

Gloves classification according to ENISO374-1: 2016

Gloves are divided into three types:

EN ISO 374-1:2016
TIPO A



UVWXYZ

TYPE A

Step time \geq 30 min for at least 6 products

EN ISO 374-1:2016
TIPO B



XYZ

TYPE B

Step time \geq 30 min for at least 3 products

EN ISO 374-1:2016
TIPO C



TYPE C

Step time \geq 10 min for at least 1 products

the advancement of chemicals at the molecular level. The resistance of the glove material to permeation by a chemical is determined by measuring the time it passes through the material.

Modification of the ENISO374-5: 2016 standard

When the glove passes the test described for virus protection, the word "virus" will appear under the pictogram. If nothing appeared, protection would only be assured against bacteria.

Letter	Chemical substance	Cas number	Class
A	Methanol	67-56-1	Primary alcohol
B	Acetone	67-64-1	Cetone
C	Acetonitrile	75-05-8	Nitrile compound
D	Dichloromethane	75-09-2	Chlorine hydrocarbon
E	Carbon disulfide	75-15-0	Sulphate organic compound
F	Toluene	108-88-3	Aromatic hydrocarbon
G	Diethylamine	109-89-7	Amine
H	Tetrahydrofuran	109-99-9	Heterocyclic ether
I	Ethyl acetate	141-78-6	Ester
J	N-heptane	142-85-5	Saturated hydrocarbon
K	Sodium hydroxide 40%	1310-73-2	Inorganic alkaline
L	Sulphuric acid 96%	7664-93-9	Inorganic, oxidising mineral acid
M	Nitric acid 65%	7697-37-2	Inorganic, oxidising mineral acid
N	Acetic acid 99%	64-19-7	Organic acid
O	Ammonia hydroxide 25%	1332-21-6	Organic alkaline
P	Hydrogen peroxide 30%	7722-84-1	Peroxide
S	Hydrofluoric acid 40%	7664-39-3	Mineral organic acid
T	Formaldehyde 37%	50-00-0	Aldehyde

Levels of resistance to permeability

Taverage penetration time	Performance levels	Average penetration time	Performance levels
> 10	Class 1	> 120	Class 4
> 30	Class 2	> 240	Class 5
> 60	Class 3	> 480	Class 6

Gloves classification according to EN374-2:2014

It is the advance of chemical products through the material, seams of the glove at a non-molecular level. Air leak test: the glove is inflated with air and immersed in water. The appearance of air bubbles is controlled within 30 '. Water leak test: the glove is filled with water and the appearance of water droplets is controlled. If these tests are positive, the pictogram will be put on.

Gloves classification according to EN374-4: 2013

Detriment to some of the glove's properties due to contact with a chemical. Eg: discoloration, hardening, softening, etc. Permeation test EN 16523-1. It is

Distributed by:

